

## Instructions for Combination Lock Pistol Box

**Step One:** To open your safe set each to on zero (0-0-0)

**Step Two:** To Change Your Code open your safe and locate the change lever on the back of the lock. Remove the red plastic tab that is located there. Move the change lever from position “B” on the left to position “A” on the right. **NOTE:** Lever will hardly move if lock is not set to (0-0-0).

**Step Three:** To reset a new code set the combination dials to your desired combination. Record your new code and place in a secure location (not in your safe).

**Step Four:** To close and lock your safe switch the change lever from position “A” back to position “B” without disturbing the combination dials and then close lid. Spin combination dials to ensure safe is locked.